

# FF-SRST Emergency Stop Module with Timer

FF-SR Series

## FEATURES

- Complies with the Machinery Directive for 98/37/EC, IEC 204, EN 60204, DIN VDE 0113 and UL 508
- Dual channel input
- Safety outputs: two direct NO contacts, one direct NC contact, two NO delayed contacts and one NC delayed contact
- Wide range of fixed and adjustable delay times
- Switching current from 1 mA to 5 A
- Automatic start or manual start mode with short-circuit detection on the push-button input
- Selectable cross-fault detection in emergency stop control circuit
- LEDs indicate power and internal relays status
- Mechanical life up to ten million operations
- Electrical life up to one million operations
- Overvoltage and short-circuit protection
- Removable terminal strips for ease of maintenance
- 45 mm / 1.77 in width

## APPLICATIONS

- Emergency stop circuits on machines
- Category 1 emergency stop circuits per EN 418 and NFPA79: delayed isolation of power after machine stoppage
- Door protection: delayed opening of an interlocked protective gate



(Direct safety contacts)



(Delayed safety contacts)



The FF-SRST Emergency Stop modules with Timer are designed to be used in emergency stop circuits where danger to personnel or machinery is present. This device has four internal standard safety relays with positive-guided contacts, of which two of these safety relays are delayed.

In the **manual start mode**, the module accepts input from the safety device (safety light curtain, safety mat, safety switches, etc.) between S21/S22 and S31/S32 after activation of the push-button between S33 and S34.

In the **automatic start mode**, the module accepts immediate input from the safety device between S21/S22 and S31/S32.

After restart, the normally open safety contacts (13/14, 23/24, 47/48, 57/58) will close and the normally closed contacts (31/32, 65/66) will open. If an emergency stop condition occurs (safety device is actuated), the normally open contacts (13/14, 23/24) will open and the normally closed contact (31/32) will close immediately. After the selected delay time has elapsed the normally open contacts (47/48, 57/58) will open and the normally closed contact (65/66) will close.

This emergency stop condition is signalled by the direct safety contacts (13/14, 23/24, 31/32) for the machine control circuitry to first stop the dangerous motion and then to remove power after a certain time by the delayed contacts (57/58, 65/66).

### WARNING

#### MISUSE OF DOCUMENTATION

- The information presented in this product sheet (or catalogue) is for reference only. DO NOT USE this document as system installation information.
- Complete installation, operation and maintenance information is provided in the instructions supplied with each product.

**Failure to comply with these instructions could result in death or serious injury.**

# FF-SRST Emergency Stop Module with Timer

## SPECIFICATIONS

### • Dual channel Emergency Stop circuits with time delayed contacts



<b>Supply voltage</b>	
Nominal voltage	24 Vac/dc (ac: ±10 %, dc: -20 %, +10 %)
Nominal power consumption	dc: 3,5 W • ac: 3,5 VA (or dc)
Nominal frequency	50 Hz to 60 Hz
Fuse protection	Internal PTC
<b>Restart input</b>	
Restart delay time	Manual start mode: 40 ms; automatic start mode: 500 ms
<b>Emergency stop inputs</b>	
Input voltage at S11	23 Vdc at nominal voltage (provided by control module)
Minimum voltage at S12, S22, S32	21 Vdc at nominal voltage
Input current between S11/S12 and S21/S22	40 mA at nominal voltage
Cable resistance between S11/S12, S21/S22, S31/S32	50 Ω (max.)
<b>Relay outputs</b>	
Relay type	Safety relay with positive guided contacts
Safety contacts	2 NO, 1 NC, 2 NO off-delayed, 1 NC off-delayed (if Y39/Y40 is jumpered)
Time delay on de-energisation	<b>Adjustable:</b> FF-SRST□□□R2: 0,06 s to 0,3 s; 0,1 s to 1 s; 0,3 s to 3 s; 0,5 s to 5 s; 1 s to 10 s; 3 s to 30 s; 30 s to 300 s / <b>Fixed:</b> FF-SRST□□□F2: 0,5 s; 1 s; 3 s; 5 s; 10 s; 30 s; 300 s ± 1 % of set value
Repeat accuracy of time delay	
Response time	Opening of inputs (S11/S12, S21/S22, S31/S32) : 15 ms; Opening in supply circuit (A1(+)/A2(-)): 40 ms
Switching capability	Power factor = 1 with resistive load
Current range (min. to max.)	1 mA to 5 A (see Note 1)
Voltage range (min. to max.)	0,1 Vac/dc to 250 Vac/dc
Typical electrical life expectancy	Power factor = 1 Vac/dc at 230 Vac (see Note 2)
2 A	1 000 000 operations
5 A	220 000 operations
Typical power factor (cos φ)	Limitation factor (see Note 3)
0,3	0,45
0,5	0,70
0,7	0,85
1	1
Operating frequency	1200 switching cycles/h (max.)
Fuse rating (external)	6 A time delayed (max.)
Mechanical life	10 million switching operations
<b>General</b>	
Temperature range	-15 °C to + 55 °C / 5 °F to 131 °F
Sealing	Housing: IP 40, Terminals: IP 20
Housing material	Thermoplastic
Vibration resistance	Amplitude: 0,35 mm; frequency: 10 Hz to 55 Hz
Connector connection (max.)	1 x 4 mm <sup>2</sup> solid [12 AWG], 1 x 2,5 mm <sup>2</sup> [14 AWG], 2 x 1,5 mm <sup>2</sup> [16 AWG] stranded wire with sleeve DIN 46288
Connector attachment	Removable block terminals with M3,5 screws; wire contacts are enclosed to prevent electrical shock
Mounting	Quick install rail mounting EN 50022-35, 35 mm x 15 mm / 1.38 in x 0.59 in size
Weight	400 g / 0.88 lb

## ORDERING INFORMATION

### FF-SRST□□□□2

Max.delay time □  
 D30: 0,3 s (adj. only)  
 D50: 0,5 s (fixed only)

□□□□  
 001: 1 s  
 003: 3 s  
 005: 5 s  
 010: 10 s  
 030: 30 s  
 300: 300 s

Voltage  
 2 = 24 Vac/dc

□□  
 R: Time adjustable  
 F: Time fixed


**Note 1: Contact damage** - To ensure the 1 mA capability during the lifetime of the contact, never exceed 300 mA or 60 V.

**Note 2:** Install arc suppressors across load to avoid module contact arcing and ensure specified contact life expectancy.

**Note 3:** Total operations = operations at power factor 1 multiplied by the limitation factor. If the power factor is 0,5 at 230 Vac and 2 A (1 000 000 operations), the limitation factor is 0,70, 1 000 000 x 0,70 = 700 000 total operations.


## CONTACT LIFE FOR 100 % RESISTIVE LOAD (TYPICAL)

Power factor = 1 (cos φ)(see Note 3)




## LIMITATION FACTOR FOR INDUCTIVE LOADS

Power factor < 1 (cos φ)(see Note 3)




### INSTALLATION DIAGRAM




### MOUNTING DIMENSIONS


Width: 45 mm/1.7 in; Height: 74 mm/2.91 in; Depth: 121 mm/4.76 in




### INTERNAL CIRCUITRY




### FRONT PANEL



### FUNCTIONAL DIAGRAM



### REMOVABLE TERMINAL BLOCKS



### SETTING OF START MODE

Start Mode	Jumper between S13/S14	Start push-button between S33/S34	
Manual start mode	●      ● not connected		This module offers the possibility to function in the automatic start mode or manual start mode.
Automatic start mode	● ——— ● connected	●      ●	Insert the start push-button between terminals S33/S34 for <b>manual start mode</b> .
			Insert a jumper between S13/S14 for <b>automatic start mode</b> to function.

### SETTING OF THE DELAYED CONTACTS

The off-delayed safety relays K1t and K2t (safety contacts 47/48 to 65/66) are only operational, if a jumper is set between Y39/Y40.



**APPLICATION EXAMPLES**

**Dual channel emergency stop circuitry (with cross-fault monitoring, manual start mode, external contactors)**

If an emergency stop condition occurs (emergency push-button or another safety device is actuated), the internal relays K1 and K2 de-energize immediately. The normally open contacts (13/14, 23/24) will open and the normally closed contact (31/32) will close. This emergency stop condition is signalled by these safety contacts for the machine control circuitry (e.g. a speed driver) to stop hazard.

The internal relays K1t and K2t will de-energize after the selected delay time has elapsed, leading to the opening of the normally open contacts (47/48, 57/58) and the closure of the normally closed contacts (65/66)(see note (D)). These contacts may be used to remove the main power of the stopped machine (category 1 emergency stop per EN 418) and NFPA79.

The emergency-stop condition can be reset while de-activating and activating the connected safety devices (inputs: S22 and S32). After restarting the module (manual or automatic restart: see note (B)), all internal safety relays K1, K2, K1t and K2t will energize immediately. All normally open contacts (13/14, 23/24, 47/48, 57/58) will close and the normally closed contacts (31/32, 65/66) will open, allowing the machine to operate (see note (D)).




**Dual-channel safety door monitoring (with cross-fault monitoring, manual start mode)**

The FF-SRST Emergency Stop module may also monitor the status of locking or interlocking devices (usually safety switches) of protective gates. When the protective gate is open, the initiation of the hazardous motion is inhibited. When the door is closed again, the next machine cycle can start, but only after initiating a manual restart sequence.

After opening the door, the two external safety switch contacts Sa and Sb will open and two internal safety relays K1 and K2 will de-energize. The normally open safety contacts (13/14, 23/24) will open and the normally closed contact (31/32) will close relaying the stop condition to the machine control circuitry. The off-delayed safety relays K1t and K2t will de-energize, the normally open safety contacts (47/48, 57/58) will open and the normally closed contact (65/66) will close after the specified time delay has elapsed (see note (D)). These delayed safety contacts may be used to isolate the machine from power (category 1 stop per EN 418) and NFPA79.

When closing the door, Sa and Sb will close and the module is ready to be restarted (see note (B)). Then, the four internal relays K1, K2, K1t and K2t will energize immediately. (see note (D)). All normally open safety contacts (13/14, 23/24, 47/48, 57/58) will close and the normally closed contacts (31/32, 65/66) will open, allowing the machine to operate.



**APPLICATION NOTES**

**Note (A): DUAL CHANNEL SAFETY DEVICES:**

This may be an emergency stop push-button in series with dual output safety switching devices (OSSD) such as safety light curtains (FF-SB, FF-LS), single beam (FF-SPS4), modular safety light curtain (FF-SCAN), safety mat (FF-SM), safety laser scanner (FF-SE), or safety limit switches (i.e. 2CLS, GK).

**Note (B): START MODES:**

**Manual start mode:** Insert start push-button between S33/S34; no jumper must be set between S13/S14.

**Automatic start mode:** Insert jumper between S13/S14; the start push-button is omitted.

**Note (C): EXTERNAL CONTACTORS:**

If contact reinforcement via external safety contactors with positive-guided contacts is necessary, the proper operation of the external contactors must be monitored by looping their normally closed contacts into the restart loop (manual start mode: S33/S34; automatic start mode: S13/S14).

**Note (D): DELAYED CONTACTS:**

The off-delayed safety relays K1t and K2t (safety contacts 47/48, 57/58, 65/66) are only operational, if a jumper is set between Y39/Y40.

## Warranty and remedy

Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Contact your local sales office for warranty information. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace without charge those items it finds defective. The foregoing is Buyer's sole remedy and is **in lieu of all other warranties, expressed or implied, including those of merchantability and fitness for a particular purpose.**

While we provide application assistance, personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

Specifications may change at any time without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

## Sales and Service

Honeywell serves its customers through a worldwide network of sales offices and distributors. For application assistance, current specifications, pricing or name of the nearest Authorised Distributor, contact a nearby sales office or:

INTERNET: [www.honeywell.com/sensing](http://www.honeywell.com/sensing)

E-mail: [info.sc@honeywell.com](mailto:info.sc@honeywell.com)

### ASIA PACIFIC

#### Australia

Honeywell Pacific Inc.  
Phone: +(61) 2-9370-4500  
FAX: +(61) 2-9370-4525  
Toll Free 1300-36-39-36  
Toll Free Fax 1300-36-04-70

#### China - PRC - Beijing

Honeywell (Tianjin) Ltd.  
Phone: +(86-10) 6561-0208  
FAX: +(86-10) 6561-0618

#### China - Hong Kong SAR

Honeywell Ltd.  
Phone: +(852) 2331 9133  
FAX: +(852) 2331 9998

#### India

Tata Honeywell Ltd  
Phone: +(91) 20 6875-532/534  
FAX: +(91) 20 6875 992

#### Indonesia

PT Honeywell Ltd.  
Phone: +(62) 21 521-3330  
FAX: +(62) 21 521-3735

#### Japan

Yamatake Corporation  
Phone: +(81) 3 5440 1395  
FAX: +(81) 3 5440 1314

#### South Korea

LG - Honeywell Co. Ltd  
Phone: +(822) 799-6114  
FAX: +(822) 792-9011

#### Malaysia

Honeywell Engineering Sdn Bhd  
Phone: +(603) 758-4988  
FAX: +(603) 758-8922

#### New Zealand

Honeywell Pty Limited  
Phone: +(64-9) 623-5050  
FAX: +(64-9) 623-5060  
Toll Free (0800) 202-088

#### Philippines

Honeywell Systems (Philippines) Inc.  
Phone: +(632) 636-1649  
FAX: +(632) 636-1650

### Singapore/SE Asia Regional Office

Honeywell Southeast Asia Pte. Ltd.  
Phone: +(65) 355-2828  
FAX: +(65) 445-3033

### Taiwan R.O.C.

Honeywell Taiwan Ltd.  
Phone: +(886) 22245-1000  
FAX: +(886) 22245 3242

### Thailand

Honeywell Systems Ltd.  
Phone: +(662) 693 3099  
FAX: +(662) 693 3085

### NORTH AMERICA

#### Canada

Honeywell LTD  
Phone: 1-800-737-3360  
FAX: 1-800-565-4130

#### USA

Sensing and Control,  
International Headquarters  
Phone: 1-800-537-6945  
1-815-235-6847  
FAX: 1-815-235-6545

### EUROPE

#### Austria

Honeywell Austria GmbH  
Phone: +(43) 1 727 80 366/246  
FAX: +(43) 1 727 80 337

#### Belgium

Honeywell SA/NV  
Phone: +(32) 2 728 2522  
FAX: +(32) 2 728 2502

#### Bulgaria

Honeywell EOOD  
Phone: +(359) 2 79 40 27  
FAX: +(359) 2 79 40 90

#### Czech Republic

Honeywell spol. s.r.o.  
Phone: +(420) 2 6112 3469/ 3424  
FAX: +(420) 2 6112 3461

#### Denmark

Honeywell A/S  
Phone: +(45) 39 55 55 55  
FAX: +(45) 39 55 55 58

### Finland

Honeywell OY  
Phone: +(358) 9 3480101  
FAX: +(358) 9 34801375

### France

Honeywell SA  
Phone: +(33) 1 60 19 82 68  
FAX: +(33) 1 60 19 81 73

### Germany

Honeywell AG  
Phone: +(49) 69 8064 444  
FAX: +(49) 69 8064 442

### Hungary

Honeywell Kft.  
Phone: +(36 1) 451 4300  
FAX: +(36 1) 451 4343

### Italy

Honeywell S.p.A.  
Phone: +(39) 02 92146 450/456  
FAX: +(39) 02 92146 490

### The Netherlands

Honeywell B.V.  
Phone: +(31) 20 565 69 11  
FAX: +(31) 20 565 66 00

### Norway

Honeywell A/S  
Phone: +(47) 66 76 20 00  
FAX: +(47) 66 76 20 90

### Poland

Honeywell Sp. zo.o  
Phone: +(48) 22 606 0900  
FAX: +(48) 22 606 0901

### Portugal

Honeywell Portugal Lda  
Phone: +(351 21) 424 50 00  
FAX: +(351 21) 424 50 99

### Romania

Honeywell Bucharest  
Phone: +(40) 1 2110076  
FAX: +(40) 1 2103375

### Commonwealth of Independent States (CIS)

ZAO Honeywell  
Phone: +(7 095) 796 98 00  
FAX: +(7 095) 796 98 93

### Slovak Republic

Honeywell s.r.o.  
Phone: +(421 7) 58247403/400  
FAX: +(421 7) 58247 415

### South Africa (Republic of)

Honeywell Southern Africa  
Honeywell S.A. Pty. Ltd  
Phone: +(27) 11 805 1211  
FAX +(27) 11 805 1354

### Spain

Honeywell S.A.  
Phone: +(34) 91 313 6100  
FAX: +(34) 91 313 6129

### Sweden

Honeywell AB  
Phone: +(46) 8 775 55 00  
FAX: +(46) 8 775 56 00

### Switzerland

Honeywell AG  
Phone: +(41) 1 855 24 40  
FAX: +(41) 1 855 24 45

### Turkey

Honeywell Turkey A.S.  
Phone: +(90) 216 4644 764  
FAX: +(90) 216 4644 794

### United Kingdom

Honeywell Control Systems Ltd  
Phone: +(44) 118 906 2600  
FAX: +(44) 118 981 7513

### Mediterranean & African Distributors

Honeywell SpA  
Phone: +(39) 2 921 46 232  
FAX: +(39) 2 921 46 233

### Middle East Headquarters

Honeywell Middle East Ltd.  
Phone: +(9712) 272533  
FAX +(9712) 269539

### LATIN AMERICA

#### Argentina

Honeywell S.A.I.C.  
Phone: +(54-11) 4 383-9282  
FAX: +(54-11) 4 325-6470

#### Brazil

Honeywell do Brasil & Cia  
Phone: +(55-11) 7266 1900  
FAX: +(55-11) 7266 1905

#### Chile

Honeywell Chile, S.A.  
Phone: +(56-2) 233-0688  
FAX: +(56-2) 231-6679

#### Columbia

Honeywell Columbia, S.A.  
Phone: +(57-1) 623-3239/3051  
FAX: +(57-1) 623-3395

#### Ecuador

Honeywell S.A.  
Phone: +(593-2) 981-560/1  
FAX: +(593-2) 981-562

#### Mexico

Honeywell S.A. de C.V.  
Phone: +(52-5) 259-1966  
FAX: +(52-5) 570-2985

#### Puerto Rico

Honeywell Inc.  
Phone: +(809) 792-7075  
FAX: +(809) 792-0053

#### Venezuela

Honeywell CA  
Phone: +(58-2) 238-0211  
FAX: +(58-2) 238-3391

This publication does not constitute a contract between Honeywell and its customers. The contents may be changed at any time without notice. It is the customer's responsibility to ensure safe installation and operation of the products. Detailed mounting drawings of all products illustrated are available on request.

© 2001 Honeywell International Inc. All rights reserved.

# Honeywell

## Honeywell Sensing & Control

21 Chemin du Vieux Chêne  
38240 Meylan Cedex

France

## Honeywell Sensing & Control

11 West Spring Street  
Freeport, Illinois 61032

USA



[www.honeywell.com/sensing](http://www.honeywell.com/sensing)