
HMR4007 Linear Position Sensor

User's Guide

SUNSTAR自动化 http://www.sensor-ic.com/ TEL: 0755-83376489 FAX:0755-83376182 E-MAIL:szss20@163.com

INTRODUCTION


The Honeywell HMR4007 is an electronic linear position sensing solution for use in commercial and industrial application environments. A stationary array of Honeywell's magnetoresistive (MR) sensors is utilized to quickly and accurately monitor the position of a small magnet attached to a moving object such as a valve stem or hydraulic cylinder. The use of a sensor array makes the solution highly insensitive to many environmental influences such as magnet strength, alignment, run out, and temperature. This solution is easily integrated into systems using a highly reliable serial interface or a 12-bit analog output (with over-range error indication).



In normal operation, a small target magnet is mounted to the moving object whose position is to be monitored and the sensor array is held stationary. The exact standoff distance (gap) is arbitrary (between 1/2" to 1-1/2") as the embedded software is highly tolerant of this gap. The sensed axis is parallel to the long axis of the sensor board. The embedded software then calculates the position of the magnetic center of the target magnet as a function of its distance along the axis of the board. The result is expressed as a 12-bit unsigned integer (or as a 12bit analog voltage). In the example to the left, if the center of the magnet was aligned with the center of the bottom-most sensor in the array, the result would be interpreted as a position of "0" while alignment with the top-most sensor would be interpreted as a position of "4095". To convert the reading to engineering units, the reported position is divided by 4095 and then multiplied by the span of the sensors (69.7mm or 2.75"). If we call the reported position "x", then the position in engineering units would be:

Position in mm = (x / 4095) * 69.6Position in inches = (x / 4095) * 2.75

The above example shows a magnet oriented in what is called the "radial" mode, where the magnetic poles point towards the sensor card. The embedded software is also capable of operating with a magnet oriented in the axial mode where the magnet poles point along the axis of the sensor as seen below. The sensor card, however, does not automatically detect the magnet mode, and a status bit in the embedded code must be set to configure the HMR4007. Software tools are available from Honeywell to easily accomplish this.



The orientation of the north and south poles is arbitrary, and the embedded software is highly tolerant of the magnet geometry so that rectangular bar magnets or cylindrical magnets can be used equally well. Cylindrical magnets in the axial mode are particularly attractive because the magnetic field is symmetrical with respect to rotation about the center axis without loss of position accuracy.

The magnet should have a minimum length of 23mm (0.91 inches) along the axis of the travel. Shorter magnets, however, can be used with some increase in the minimum gap between the magnet and sensor board as long as a minimum field strength of 80 gauss and an **apparent** magnet length of 23 mm is maintained at the sensor board. More on apparent magnet length can be found in the application notes at the end of this document.

HMR4007

SENSOR PRODUCTS

SPECIFICATIONS

Characteristics	Conditions	Min	Тур	Max	Units
General		L			
Accuracy		0.2	0.1		mm
Resolution		0.1		mm	
Hysteresis			0.01		mm
Repeatability			0.01	0.1	mm
Update Rate		10	30		Hz
Standoff	Distance (gap) between the target magnet and the sensor board	Distance (gap) between the target 0.1 5 (note 1)		mm	
Magnetic Field					
Range	magnetic field at the sensor array	80(note 1)			gauss
length	apparent magnet length at sensor array	23	(note 3)		mm
Orientation			Axial (note 2)		
Electrical					
Input Voltage	Unregulated	6		28	VDC
Current			15	20	mA
Digital Interface					
Baud Rate	nonstandard synchronous serial interface	1000		21,000	Bits / sec
Signaling Level	TTL levels ("1")	3.5		5.0	VDC
	("0")	-0.3		1.5	VDC
Connector	In-Line 6-Pin Block (0.1" spacing)				
Analog Interface					
Analog Output	D/A output	0	2.5		VDC
Update Rate		10	30		Hz
Signaling Level	TTL levels ("1")	3.5		5.0	VDC
	("0")	-0.3		1.5	VDC
Connector	In-Line 4-Pin Block (0.1" spacing)				
Physical					
Dimensions	Circuit Board Assembly		40.0 x 80.0 x		mm
	(including connectors)		12.0		
Weight	HMR4007	16.5		grams	
Environment					
Temperature	Operating	-40	-	+70	°C
	Storage	-55	-	+125	

however, must be used to maintain a magnetic field strength of 80 gauss (min.) at the sensor array and an apparent magnet length of 23 mm.

Note 2: Sensor boards are factory calibrated in the axial mode using a 27mm cylindrical magnet. Operation in the radial mode must be configured by the user. TEL: 0755-83376489 FAX:0755-83376182 E-MAIL:szss20@163.com

Note 3: cf. "Magnet Considerations" (pg. 8)

PIN CONFIGURATION

	Pin Number	Pin Name	Description
--	------------	----------	-------------

Digital Interface

1	RTS	Serial Clock Output
2	Data_Out	Serial Data Output
3	Data_In	Serial Data Input
4	CTS	Serial Clock Input
5	Power	Unregulated Power Input (+6 to +28 VDC) (see note 1)
6	GND	Power and Signal Ground

Analog Interface

1	Power	Unregulated Power Input (+6 to +28 VDC) (see note 2)
2	Analog Out	0 - 2.5 VDC analog output
3	Position Valid	TTL level (0 = position invalid, 1 = position valid)
4	GND	Power and Signal Ground

Jumper Block #1

2-5	Note 1	Analog Output port selected as power source
3-6	Note 1	Serial Communications port selected as power source

Note 1: The board contains three interface connectors for digital and/or analog communications. Power is supplied to the board through any one of these connectors and is selected by jumper block #1. All of the ground connections on all three ports are common to the circuit ground and are not affected by the jumper position. Only *ONE* of the three positions on JP1 should be shorted at a time. Shorting more than one may result in excessive power supply currents and board damage.

CIRCUIT DESCRIPTION

The HMR4007 Linear Position Sensor circuit board includes all of the basic sensors and electronics to provide a digital indication of position of a target magnet. The HMR4007 starts with an array of seven Honeywell HMC1501 single axis magnetoresistive (MR) sensors to determine the field geometry and direction of a target magnet attached to the moving part of a device under test. These sensors are supplied power by a constant voltage source, and the use of an array of sensors helps to maintain accuracy over temperature and run-out. The sensor outputs are routed to a multiplexed Analog to Digital Converter (ADC) integrated circuit. A microcontroller integrated circuit periodically queries the multiplexed ADC and performs sensor offset and gain corrections and computes the position data, along with an error bit, is available thought the serial interface or is present on the Digital to Analog Converter (DAC) output port. *The serial interface is not needed in order to use the board's stand-alone analog output.* The microcontroller also performs the external serial data interface and other housekeeping functions. An onboard EEPROM integrated circuit is employed as a nonvolatile storage to retain necessary data and configuration variables for best performance.

The HMR4007 uses an on-board low drop out (LDO) +5 volt regulator so that a regulated +5 volt power supply or an unregulated power supply in the range of +6VDC to +28VDC can be used. The power is supplied to the board through one of the three user ports being (serial, analog, or USB) and a jumper is used to select which port is the power source. Only one jumper should be in place at any one time as the board does not have over current protection and use of more than one jumper can result in excessive power supply currents and board damage.

PHYSICAL CHARACTERISTICS

The circuit board for the HMR4007 Linear Position Sensor is approximately 340mm by 80mm. A 6-pin right angle connector (J1) and two 4-pin connectors (J2, J3) protrude from the back of the board for user connections. Components on the top-side have a maximum height of 12mm. Figure 1 shows a typical circuit board with dimensions.

PARTS PLACEMENT




Figure 1 – Sensor board layout and connector pin designations

MATING PARTS

Connectors J1, J2, and J3 mate with GC/Waldom C-Grid[™] crimp-style shells and terminals. Polarized shells (with a locking tab) or unpolarized shells are available. The applicable GC/Waldom part numbers are:

Connector	pins	Polarized shell	Unpolarized shell	Crimp terminals
J1	6	50-57-9406	50-57-9006	16-02-0097
J2	4	50-57-9404	50-57-9004	16-02-0097
J3	4	50-57-9404	50-57-9004	16-02-0097

SUNSTAR自动化 http://www.sensor-ic.com/ TEL: 0755-83376489 FAX:0755-83376182 E-MAIL:szss20@163.com

HMR4007

SENSOR PRODUCTS

Honey

APPLICATION NOTES

USING THE HMR4007 AS A STAND ALONE SENSOR

Introduction

The HMR4007 can be used as a stand-alone sensor without the need for any digital communications. The board is configured at the factory to provide a 0-2.5 VDC analog output (axial magnet) and status signal that represents the position of the magnet along the long axis of the device. All power and signals are available on connector J2.

Connector J2 General Description

When used in a stand-along mode, only connector J2 needs to be used. Connector J2 is a 4-pin socket header that is used to supply power (pin 1), ground (pin 4), analog position (pin 3), and status (pin 2). When power is supplied to the board though J2, a jumper must be placed on pins 2-5 (center pair) in jumper block JP2. The power supply can be regulated 5VDC or unregulated 6-28VDC. If connector J2 is used in combination with the communications port, only **ONE** of the ports should be used to supply power to the board.

Analog Outputs

The analog output (J2, pin 3) represents the position of the magnet along the long axis of the sensor board as seen in Figure 2 below. In the given example, the center of the magnet lies between sensors 3 and 4. The resulting output voltage is 1.20 volts which corresponds to a position of 33.4 mm.




Figure 2. Position sensing example.

An effort should be made to keep the angle of the magnet with respect to the sensor board reasonably constant along the length of travel. The sensor, however, is guite tolerant to changes in distance (gap) between the sensor and magnet along the length of travel.

Status Pin

Pin 2 (on port J2) is a TTL logic-level status output bit. This pin will be logic high (+5VDC) whenever the position output is valid. Logic level low (ground) indicates that the sensor cannot calculate a magnet position. The most likely causes of a position error signal are:

- 1. The magnet is beyond the sensed range of the device.
- 2. The magnet is too short or too weak for the sensors to track.

3. The gap between the sensor and magnet is too large. SUNSTAR The magnet is worspresent: .com/ TEL: 0755-83376489 FAX:0755-83376182 E-MAIL:szss20@163.com

USING THE HMR4007 IN DIGITAL COMMUNICATIONS MODE

Introduction

The HMR4007 is capable of communicating with a higher-level system through a proprietary communications port (J1). This port uses a bit-clocked serial protocol for higher speed and higher data integrity than standard serial protocols. Signal levels are standard TTL compatible. For convenience, a windows-based DLL (dynamic link library) and sample Visual Basic demonstration program are available from Honeywell that communicates with the sensor through a PC's parallel port. Interested developers should contact their Honeywell representatives or the factory for details of the communications protocol and command structure. The communications port can be used independently or in combination with the analog output described earlier. When used in combination with the analog port, only **ONE** port should be used to supply power to the board. Sensor configuration, such as changing the magnet mode from axial to radial, is available only through the communications port and DDL calls are supplied to support these basic functions.

Connector J1 General Description

J1 is a 6-pin header which is wired to a PC parallel port for digital communications with the Honeywell demonstration DLL software (or other user application) using the following connections:

	Sensor Board		
data direction	J1 pin	function	color
<	1	RTS	(gray)
<	2	Data_Out	(yellow)
>	3	Data_In	(blue)
>	4	CTS	(white)
<>	5	+5-28 VDC	(red)
<>	6	power gnd	(black)
	direction < < > > <>	data direction J1 pin <	data directionJ1 pinfunction<

Demonstration Software

Two programs are included with this board to demonstrate its operation.

HMR4007.dll is a dynamic link library that performs low level communications between the host PC's parallel port and the sensor board to query the current, measured position and support operating mode changes. Several functions are visible to the user using the following Visual Basic header formats:

Declare Function InitPort Lib "HMR4007.dll" (ByVal ADD As Integer, ByVal TOut As Long) As Integer Declare Function CurrentPosition Lib "HMR4007.dll" () As Integer Declare Function SetAxialMode Lib "HMR4007.dll" () As Integer Declare Function SetRadialMode Lib "HMR4007.dll" () As Integer Declare Function EnableDAC Lib "HMR4007.dll" () As Integer Declare Function DisableDAC Lib "HMR4007.dll" () As Integer

The first function, "InitPort", is used to setup the PC's parallel port base address (default is 0x378) and timeout value. This function must be called before any calls to the operating functions.

The port base address (ADD) is the address of the computer's parallel (printer) adapter and used by the software as a base address to send and receive data to the sensor card through the parallel port adapter. The value is passed as a 16-bit integer. Setting this value to -1 re-initializes the port with the previous value (or default value) retained.

The timeout value (Tout) is used as an internal loop counter to return to the calling program after a fixed time if for some reason the sensor board fails to respond. A value of 10,000 is the default and works well on a 100MHz Pentium-class machine. Higher values will be needed for faster machines. The parameter is passed as a 32-bit long integer. Passing a value of -1 sets the value to the previous (or default) value. SUNCTAR FAULT INTEGER AND THE INTEGER TO THE FUNCTION OF THE STATE OF THE ST

The second function, "CurrentPosition", is used to query the current position of the magnet. The following 16-bit integer values are returned:

- 0-1024 **normal position response** where 1024 represents full scale response.
- -1, -2 **communications failure.** The sensor failed to respond to the PC quickly enough. This is usually caused by improper wiring, improper power settings, a timeout value too small for the PC speed, or the DLL not being initialized before attempting to get the position.
- -3 **position error**. The sensor communicated correctly, but the sensor card was not able to calculate a valid position. A position error is usually caused by the magnet being off the end of the board or not present.


The functions "SetAxialMode" and "SetRadialMode" are used to configure the sensor to use magnets in either the axial mode or radial (see the introduction for a description of axial and radial modes). The sensor is shipped with the axial mode selected. Once set into an operating mode, that mode is retained in nonvolatile RAM.

The functions "EnableDAC" and "DisableDAC" are used to enable and disable the digital to analog (DAC) output on port J2. The sensor is shipped with the DAC enabled. Once set into an operating mode, that mode is retained in nonvolatile RAM.

HMR4007.exe: This is a simple Visual Basic 5.0 executable that demonstrates the use of the DLL and shows a simple graphical display of the current position. Source code for the program is available and can be modified as desired. The position window will turn yellow in the event of a communications failure, or turn red in the event of a position error.

MAGNET CONSIDERATIONS

The choice of magnet to be used with the HMR4007 is critical to its accuracy. Because a magnet's field extends beyond the boundaries of the material, a magnet has two dimensions to consider: its physical (material) length and its apparent (magnetic) length. The heart of the HMR4007 is Honeywell's HMR1501 magnetoresistive (MR) sensor that responds to the angle between the chips' sensitive axis and the magnetic field. The HMR1501 has a maximum response when this angle is +/-45 degrees. We can, therefore, define the magnet's apparent length as the distance between the +45 and -45 degree points at the gap distance.



As the gap between the magnet and the sensor array increases, the apparent length of the magnet increases as well. A general rule of thumb for a cylindrical bar magnet is that the apparent length will increase by the amount of the gap. A twenty-five millimeter long magnet for example will appear to be thirty-five millimeters long at a gap of 10 millimeters. Since magnetic fields are highly nonlinear and subject to the exact geometry and properties of the material, this is only a general guide.

The HMR4007 uses three sensors in its array at all times in order to calculate position. It automatically selects the sensors closest to the magnet for this purpose. The apparent magnet length must, therefore be greater than he spacing between three sensors, and this distance is 23.2mm for the HMR4007.

The disadvantage of increasing the gap between the sensor and magnet in order to increase its apparent length is that a magnet's field strength decreases exponentially with gap. In order to maintain the MR sensor's response the magnetic field **at the sensor** must be greater than 35 gauss. Unless extremely strong rare earth magnets are economically feasible or a large gap is required because of restrictions on where the magnet and array can be mounted, it is usually better to keep the gap to a minimum and use a longer magnet.

Figure 3. Magnet apparent length

SUNSTAR商斯达实业集团是集研发、生产、工程、销售、代理经销、技术咨询、信息服务等为一体的高 科技企业,是专业高科技电子产品生产厂家,是具有10多年历史的专业电子元器件供应商,是中国最早和 最大的仓储式连锁规模经营大型综合电子零部件代理分销商之一,是一家专业代理和分銷世界各大品牌IC 芯片和電子元器件的连锁经营綜合性国际公司。在香港、北京、深圳、上海、西安、成都等全国主要电子 市场设有直属分公司和产品展示展销窗口门市部专卖店及代理分销商,已在全国范围内建成强大统一的供 货和代理分销网络。 我们专业代理经销、开发生产电子元器件、集成电路、传感器、微波光电元器件、工 控机/DOC/DOM电子盘、专用电路、单片机开发、MCU/DSP/ARM/FPGA软件硬件、二极管、三极管、模 块等,是您可靠的一站式现货配套供应商、方案提供商、部件功能模块开发配套商。专业以现代信息产业 (计算机、通讯及传感器)三大支柱之一的传感器为主营业务,专业经营各类传感器的代理、销售生产、 网络信息、科技图书资料及配套产品设计、工程开发。我们的专业网站——中国传感器科技信息网(全球 传感器数据库)www.SENSOR-IC.COM 服务于全球高科技生产商及贸易商,为企业科技产品开发提供技 术交流平台。欢迎各厂商互通有无、交换信息、交换链接、发布寻求代理信息。欢迎国外高科技传感器、 变送器、执行器、自动控制产品厂商介绍产品到 中国,共同开拓市场。本网站是关于各种传感器-变送器-仪器仪表及工业自动化大型专业网站,深入到工业控制、系统工程计 测计量、自动化、安防报警、消费电 子等众多领域,把最新的传感器-变送器-仪器仪表买卖信息,最新技术供求,最新采购商,行业动态,发展方 向,最新的技术应用和市场资讯及时的传递给广大科技开发、科学研究、产品设计人员。本网站已成功为 石油、化工、电力、医药、生物、航空、航天、国防、能源、冶金、电子、工业、农业、交通、汽车、矿 山、煤炭、纺织、信息、通信、IT、安防、环保、印刷、科研、气象、仪器仪表等领域从事科学研究、产 品设计、开发、生产制造的科技人员、管理人员 、和采购人员提供满意服务。 我公司专业开发生产、代 **理、经销、**销售各种传感器、变送器、敏感元器件、开关、执行器、仪器仪表、自动化控制系统: 专门从 事设计、生产、销售各种传感器、变送器、各种测控仪表、热工仪表、现场控制器、计算机控制系统、数 据采集系统、各类环境监控系统、专用控制系统应用软件以及嵌入式系统开发及应用等工作。如热敏电阻、 压敏电阻、温度传感器、温度变送器、湿度传感器、 湿度变送器、气体传感器、 气体变送器、压力传感 器、 压力变送、称重传感器、物(液)位传感器、物(液)位变送器、流量传感器、 流量变送器、电流 (压) 传感器、溶氧传感器、霍尔传感器 、图像传感器、超声波传感器、位移传感器、速度传感器、加速 度传感器、扭距传感器、红外传感器、紫外传感器、 火焰传感器、激光传感器、振动传感器、轴角传感器、 光电传感器、接近传感器、干簧管传感器、继电器传感器、微型电泵、磁敏(阻)传感器 、压力开关、接 近开关、光电开关、色标传感器、光纤传感器、齿轮测速传感器、 时间继电器、计数器、计米器、温控仪、 固态继电器、调压模块、电磁铁、电压表、电流表等特殊传感器 。 同时承接传感器应用电路、产品设计 和自动化工程项目。

欢迎索取免费详细资料、设计指南和光盘;产品凡多,未能尽录,欢迎来电查询。 更多产品请看本公司产品专用销售网站: 商斯达中国传感器科技信息网: http://www.sensor-ic.com/ 商斯达工控安防网: http://www.pc-ps.net/ 商斯达电子 元器件网: http://www.sunstare.com/ 商斯达微波光电产品网:HTTP://www.rfoe.net/ 商斯达消费电子产品网://www.icasic.com/ 商斯达军工产品网:http://www.junpinic.com/ 商斯达实业科技产品网://www.sunstars.cn/传感器销售热线: 地址: 深圳市福田区福华路福庆街鸿图大厦 1602 室 电话: 0755-83607652 83376489 83376549 83370250 83370251 82500323 传真: 0755-83376182 (0) 13902971329 MSN: SUNS8888@hotmail.com 邮编: 518033 E-mail:szss20@163.com QQ: 195847376 深圳赛格展销部:深圳华强北路赛格电子市场 2583 号 电话: 0755-83665529 技术支持: 0755-83394033 13501568376