

1.工作電壓範圍：2.4~5.5V

2.共有 65key

37 鍵黑白鍵, (音域 F3~F6).

15 首 Dual Tone 歌曲(Song1~Song15)

4 個鼓鍵(Drum1~Drum4)

1 個步進鍵(OKON)

1 個鼓組節奏鍵(Fill-in)

1 個 Demo Next 鍵

1 個 Demo All 鍵

1 個舞曲節奏鍵(Rhythm)

1 個 ECHO 鍵(Echo)

1 個鋼琴鍵(Piano)

1 個電吉它鍵(E-Guitar)

1 個 Stop 鍵.

直推喇叭

內鍵 RC 振盪器 OSC 外部電阻可自選,接或不接電阻零件.

## 二、功能說明:

1 黑白鍵:

按下任何一鍵會發出該鍵相對應的鋼琴或 E-Guitar 的音符.

2,15 首 Dual Tone 歌曲

按下 Song1~Song15 中任意鍵則會播放相對應的 Dual Tone 歌曲

3,鼓組節奏鍵(FILL-IN).

4,4 個鼓組鍵(Drum1~Drum4)

若 Drum1~Drum4 任何一個鍵按下時,播放對應的鼓聲,當再按鼓組節奏鍵時,首先 PLAY 兩遍最後一個按鍵相對應節奏聲,然後進入主節奏,主節奏重複播放.

5 ECHO 鍵

按下此鍵,再按 Drum1~Drum4 則會播放相對應的鼓的 ECHO 聲,鍵盤聲亦會 ECHO.

6 舞曲節奏鍵

按下此鍵,則可以 SEQ 方式播放 8 种舞曲節奏.

7One Key One Note

在歌曲模式下,按下 OKON 鍵,則可按任何一個黑白鍵,播放出相對應的歌曲音符.

8 鋼琴鍵

按下 Piano 鍵后,再選擇任何一個黑白鍵則會發出相對應的鋼琴音符.

9 E-Guitar.

按下此鍵后,再選擇任何一個黑白鍵則會登出相對應 E-Guitar.

10 無語音半分鐘后自動 Sleep.

## 二、Song List:

SUNSTAR单片机专用电路 <http://www.icasic.com/> TEL: 0755-83387030 FAX:0755-83376182 E-MAIL:szss20@163.com

序号	文件名	歌名
1	LBI2.TXT	London Bridge
2	MHA3.TXT	Mary Had A Little Lamb
3	JB1.TXT	Jingle Bell
4	OMH2.TXT	Old MacDonald Had A Farm
5	OS1.TXT	Oh Susanna
6	TWINKLE.TXT	Twinkle Twinkle Little Star
7	ATI.TXT	A-Tisket A-Tasket
8	SFD.TXT	Shoo Fly, Don't Bother Me
9	BBFT.TXT	Bicycle Built For Two
10	MB.TXT	My Bonnie Lies Over The Ocean
11	TLK.TXT	Little Kittens
12	SASO1.TXT	Sing A Song Of Sixpence
13	WTSG.TXT	When The Saints Go Marching In
14	PWD2.TXT	Polly Wolly Doodle
15	HCB.TXT	Hot Gross Buns

## 四、Drum List:

- 鼓 1、E.Snare Drum
- 鼓 2、HighTimbale
- 鼓 3、Acoustic Bass Drum
- 鼓 4、Cymbal