


# MAXTEC

## SERIAL NUMBER DEFINITION

Maxtec® Oxygen Sensor serial numbers are located on the oxygen sensor label. The Lot Number, Job Number, Line Item Number and Sequence Number all relate to the sequence of when the sensor was manufactured, during the month it was manufactured. The model number is listed separately on the label.



- |          |                                    |
|----------|------------------------------------|
| V - 2010 | MONTH IN WHICH THE LOT WAS STARTED |
| W - 2011 |                                    |
| X - 2012 | A - JAN                            |
| Y - 2013 | B - FEB                            |
| Z - 2014 | C - MAR                            |
| A - 2015 | D - APR                            |
|          | E - MAY                            |
|          | F - JUN                            |
|          | G - JUL                            |
|          | H - AUG                            |
|          | J - SEPT                           |
|          | K - OCT                            |
|          | L - NOV                            |
|          | M - DEC                            |



6526 South Cottonwood Street • Salt Lake City, UT 84107  
 Telephone: 801-266-5300 • Fax 801-270.5590  
 Toll Free U.S.A. 1- (800) 748-5355  
 Home page: <http://www.maxtecinc.com>